



Suggested Vehicular Protection for Meters and Regulators

Residential/Small Commercial



Commercial/Industrial



THE BEST SOLUTION IS TO AVOID INSTALLING THE GAS METER AND PIPING WHERE VEHICLES COULD ACCIDENTALLY RUN INTO THE GAS METER AND PIPING. IT IS THE RESPONSIBILITY OF THE CUSTOMER TO PROVIDE A SAFE LOCATION FOR NEW GAS METERS AND REGULATORS. IF THIS IS NOT POSSIBLE, METER PROTECTION IS USUALLY NEEDED. THE CUSTOMER, THE BUILDING INSPECTOR, OR THE COMPANY CAN DETERMINE IF METER SET PROTECTION IS NEEDED. WITHOUT IT, VEHICULAR TRAFFIC COULD ACCIDENTALLY COLLIDE WITH THE GAS FACILITIES CAUSING A POTENTIALLY DANGEROUS SITUATION WHICH COULD RESULT IN SERIOUS INJURY OR DAMAGE. PROTECTION USUALLY CONSISTS OF ONE OR MORE 4" OR LARGER STEEL POSTS. A 6" CONCRETE CURB CAN ALSO BE USED. THE CUSTOMER CAN INSTALL EITHER POST OR 6" CURB. THE COMPANY WILL INSTALL POSTS FOR A FEE. THIS USUALLY CONSISTS OF ONE OR MORE POSTS OR PROTECTORS.

PLEASE CALL THE COMPANY FOR ASSISTANCE IF YOU HAVE OR THINK YOU MAY HAVE A POTENTIALLY DANGEROUS METER LOCATION.

1. THE DRAWINGS ABOVE ARE TYPICAL POST LAYOUTS FOR AREAS WHERE PROTECTION IS NEEDED.
2. WHEN INSTALLING THE POSTS, USE GOOD JUDGEMENT IN AREAS SUCH AS ALLEYS, DRIVEWAYS, WALKWAYS, ETC.
3. THE POST SHOULD BE BURIED TO A DEPTH OF 30" AND SHOULD EXTEND 36" ABOVE THE GROUND. TAMPED GRANULAR MATERIAL SHALL BE USED AROUND POST OR USE APPROXIMATELY ONE FOOT OF CONCRETE OR SPEED-CRETE, AND FILL THE BALANCE OF THE HOLE WITH TAMPED GRANULAR MATERIAL. POSTS SHALL NOT BE DRIVEN. ALWAYS CALL DIGGERS' HOTLINE AT 1-800-242-8511 PRIOR TO MAKING ANY EXCAVATIONS.
4. POSTS SHOULD BE LEVEL AND PLUMB WITH OTHER POSTS. FILL THE POST WITH SAND OR GRAVEL AND CAP OFF WITH CONCRETE.

Revised: 03/10